

DODGE Trucks ('03-'09)



- 1) Remove Plastic caps with a flat blade screw driver revealing the hidden bolts.



- 2) Remove the two bolts with a 10mm socket.



- 3) **PASSENGER SIDE:**
Slide the two larger bushings over the stock plastic mount (this is what breaks)



Continued on Next Page ►



If you need more assistance, we are only a phone call away.

(770) 886-2500

Monday-Friday
8:30am-5:30pm EST

GENO'S GARAGE, INC.
1150 Samples Industrial Drive
Cumming, Georgia 30041

Installation: A-Pillar Repair Kit



4) Insert the two bolts into the smaller bushing and then into A-pillar trim and tighten.

5) Insert plastic caps.



6) **DRIVER'S SIDE:**

You must first trim back the tabs which are protruding from the area in which the larger bushings slides over. This can be done with a pair of side cutters, grinder or file.



7) Slide the two larger bushings over the stock plastic mount (this is what breaks)

8) Insert the two bolts into the smaller bushing and then into A-pillar trim and tighten.

9) Insert the plastic caps.

Congratulations, you've just made your vehicle safer to enter and exit.